


MULTIPLE TECHNOLOGY AIR PURIFIER

MODEL NO: PM 505



INSTRUCTION MANUAL

Thank you for purchasing the innovative PureMate Air Purifier PM505 . We wish you many years of healthy indoor air with this efficient and effective product.

SAFETY INSTRUCTIONS

Ensure that all safety precautions are followed when using electrical appliances for the proper operation of the device.

This instruction booklet describes the safety precautions to be observed during operation to prevent injuries to yourself, other persons and damage to the device. The content not only is suitable for this product but also suitable for electrical appliances in general.

- To avoid fire or shock hazard, plug the appliance directly into a 220-240V~ 50Hz electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- Keep unit away from heated surfaces and open flames.
- To protect against electrical hazards, DO NOT immerse in water or other liquids.
 Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Please Call Customer Service for assistance.
- Use appliance only for intended household use as described in this manual. Any
 other use not recommended by the manufacturer may cause fire, electric shock or
 injury to persons.
- DO NOT use outdoors.

- NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- DO NOT place anything on top of unit.
- To prevent interference and distortion the device should be placed at least 1 meter away from computer, television or radio.

WARNING: To reduce the risk of fire or electric shock, do not use this unit with any solid-state speed control device.

HOW IT WORKS

Improve your indoor air quality with your new PureMate Air Cleaning System. Multiple levels of cleaning include a combination True HEPA filter that captures allergens, and Charcoal filter to remove odours.

Pre-Filter

Captures initial dust and allergen particles.

Activated Carbon

Charcoal/Activated Carbon contributes to the control and prevention of the growth of bacteria, germs and mould.

True HEPA Treatment Filter

Captures 99.97% of dust and allergens.


Cold Catalyst Filter

The cold catalyst can absorb the formaldehyde. It has a very. strong ability to remove formaldehyde. Cold catalyst is another new type of air purification material after Photo catalyst air purification material.

Air Ioniser

The most important benefit of negative ions is that they clear the air of airborne allergens such as pollen, mould spores, bacteria and viruses. Besides they also clear the air of dust, pet dander and cigarette smoke from the air.

5 STAGES AIR CLEANING SYSTEM



- 1. Carefully remove your air purifier from the gift box and the bag.
- 2. Remove the back cover and remove the filter from the bag.
- 3. Select a firm level and flat location. For proper air flow, locate the unit at least 1 foot (0.3 M) from any wall or furniture. Ensure no grills are blocked.
- 4. Plug the power cord into a 220-240V~50hz outlet.
- 5. Always lift your air purifier by the handle of the unit.

WHAT IS CADR?

CADR stands for "Clean Air Delivery Rate" which indicates the volume of filtered air delivered by an air purifier. CADR ratings show the effectiveness of how efficient the air purifier is at capturing fine particules from things like tobacco smoke and plant pollens from the room.


Clean Air Delivery Rate

From air cleaner to air cleaner, compare the CADR numbers. First look at suggested room size. Then refer to the Clean Air Delivery Rate (CADR) numbers. The higher the number, the faster the unit filters the air.


This air cleaner is suggested for use in a single, closed room up to 255 square feet.

Higher CADR rates provide improved performance in all room sizes. Portable air cleaners will be much more effective in rooms when all the doors and windows are closed

COMPONENTS



CONTROL PANEL



OPERATING INSTRUCTIONS

The air purifier may be operated by the manual controls located on the air purifier (as shown in **Control Panel**).

POWER ON/OFF: Turns the air purifier power ON/OFF.

- Press the POWER ON/OFF button. The device starts operating.
- Press POWER ON/OFF again and the device will stop working.

FAN SPEED/AIR FLOW: There are three fan speed options: Low, Medium, and High.

ION ON/OFF: Press the ION button to turn the Ioniser functions ON and OFF. The LED indicator light will show when this function is ON.

TIMER: Sets an Auto- Timer ON or Auto – Timer Off to choose between 1H, 2H, or 4 hour setting.

- Setting Auto –Timer On: If the timer is selected when the unit is off, the unit will turn on after the selected time.
- Setting Auto –Timer Off: If the timer is selected whilst in use, the unit will turn off after the selected time.

SLEEP BUTTON: Press Sleep Mode to turn off all the lights except the slight illumination of the Sleep Mode button. Touching the Sleep Mode button again it will illuminate the functions in use. The unit will continue working on the low fan mode but the lights will turn off.

Filter Reset: Turn on the power, touch the " ① "button to turn on the unit. And long press the " ③ + ② "button for 3 seconds to reset the air purifier.

TO REPLACE THE FILTER:

We advise cleaning the filter with a vacuum cleaner once a month, and replacing it once a year or every 4000 hours of use, whichever one comes first, to ensure good quality clean and fresh air. Following 4000 hours of use, the timer LED's will flash continuously as a reminder to replace the filter. After you have fitted a new filter, hold the power button and the fan speed button for 3 seconds to reset the air purifier.

Instructions:

- Remove the back panel of the air purifier by holding the upper part of the panel and lifting upwards and away from the unit.
- Remove the composite filter by pulling the two tabs at the top of the filter.
- Ensure that the new filter is fitted in the same direction with the blue side and pulling tabs facing outwards.
- Reattach the back panel filter.

*Filter Replacement Indicator: When the Timers 3 LED lights illuminate and flash, on the control panel. it is time to replace your filter this indicates the filter needs replacing.

Replace the filter according to directions, turn on the power, touch the "0" button to turn on the unit. And long press the "0+0" button for 3 seconds to reset the air purifier.

Thank you for purchasing the innovative PureMate Air Purifier PM505 . We wish you many years of healthy indoor air with this efficient and effective product.

SAFETY INSTRUCTIONS

Ensure that all safety precautions are followed when using electrical appliances for the proper operation of the device.

This instruction booklet describes the safety precautions to be observed during operation to prevent injuries to yourself, other persons and damage to the device. The content not only is suitable for this product but also suitable for electrical appliances in general.

- To avoid fire or shock hazard, plug the appliance directly into a 220-240V~ 50Hz electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- Keep unit away from heated surfaces and open flames.
- To protect against electrical hazards, DO NOT immerse in water or other liquids.
 Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.
- DO NOT cover cord with throw rugs, runners, or similar coverings.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Please Call Customer Service for assistance.
- Use appliance only for intended household use as described in this manual. Any
 other use not recommended by the manufacturer may cause fire, electric shock or
 injury to persons.
- DO NOT use outdoors.

CLEANING & MAINTENANCE

- Your appliance must be switched OFF via the main power supply and unplugged before proceeding with any cleaning.
- To clean the exterior surfaces simply wipe over with a clean, dry soft cloth. Avoid all other types of detergents, cleaners, solvents that may contain chemicals, which could damage parts of the unit.
- Never use flammable or abrasive cleaning agents such as benzene or spirits to clean the appliance.
- Clean the filter monthly with the brush or nozzle of your vacuum cleaner.
- Never immerse the appliance in water.
- Never spray the appliance with liquids or submerge it in water or any other liauid.
- Do not stick any foreign objects or your fingers inside the unit.

SPECIFICATIONS

Model:	PM 505
Rated Voltage:	220-240V~50Hz
Power Consumption:	22W(Low Setting) 45W (Highest Setting)
Noise Level:	Silent fan 20 dB(A) (Low), 60 dB(A) (HI)
Negative lons:	≥ 40 millions/cm³
Removal Rate:	Up to 99.97%
CADR Rating (High speed):	210 m³/hour
Applicable Area:	up to 430 ft² (40 m²)
Dimensions (L x W x H):	33(L)x 17(W) x 51(H) CM
Net Weight:	4.5kg

Replacement Filter: You can buy the replacement filter Model No: PM 505HF for this Air purifier.

DISPOSAL OF THIS DEVICE



At the end of the product life cycle, you should not throw this machine into the normal household garbage but bring the product to a collection point for the recycling of electrical and electronic equipment.