



PERSONAL IONIC AIR PURIFIER

MODEL NO: PM 86



INSTRUCTION MANUAL

Thank you for choosing the PureMate Personal Ionic Air Purifier.

SAFETY INSTRUCTIONS

Ensure that all safety precautions are followed when using electrical appliances for the proper operation of the device. This instruction booklet describes the safety precautions to be observed during operation to prevent injuries to yourself, other persons and damage to the device. The content not only is suitable for this product but also suitable for electrical appliances in general.

- Rated Voltage DC 3V
- Keep away from flammable, combustible and explosive materials.
- DO NOT immerse in any liquids.
- Keep out of direct sunlight or near high temperatures.
- To prevent electric shock, do not dismantle, repair or modify this product. In case of malfunction, contact PureMate Customer Service.

PRODUCT OVERVIEW

The PM 86 Personal Ionic Air Purifier is worn around the neck. It uses plasma breeze technology to deliver ion rich air to your mouth and nose, providing you with clean and healthy air wherever and whenever you go.

The hanger strap may be adjusted to suitable length as required. It's elegantly designed and compact and weighs just 55 grams (0.12 lbs) which makes it really portable.

COMPONENTS



NOTE: The auto-shut off timer inside the unit will make the unit to stop working in 30 minutes after it's turned on.

OPERATING INSTRUCTIONS

The unit is operated through DC power source.

- Push open the cover of batteries compartment at the back of the unit and install 2 AAA batteries according to the positive (+) and negative (-) signs on the cover. Then close the cover and make sure the compartment is locked.
- Press the POWER button on front of unit. The Green indicator light indicates the unit is operating.
- The auto-shut off timer inside the unit will make the unit to stop working in 30 minutes after it's turned on.
- If you want to stop the unit in midway, simply press the power button once.
- Please adjust the strap to suitable length for the unit to be hung 20 cm under your mouth and nose.

CLEANING & MAINTENANCE

- After about 3 months of operation, front cover should be opened and cleaned.
- Use cotton swab and rubbing alcohol to wipe through the collector ring and electrode pins inside the purifier.
- After cleaning, please lock the front cover again and let the unit dry thoroughly before using.

SPECIFICATIONS

| | |
|-------------------------------|----------------------------------------------------------|
| Model: | PM 86 |
| Rated voltage: | DC 3V 2 AAA batteries (Not included) |
| Power consumption: | 0.5 W |
| Ion output Max. : | 10,000/cm ³ |
| Active oxygen output approx.: | 0.015 – 0.03 ppm |
| Dimensions : | 9.20 cm (H) x 4.90 cm (W) x 2.90 cm (L) |
| Weight: | 55g |
| Applicable area: | This purifier is designed specifically for personal use. |

DISPOSAL OF THIS DEVICE



At the end of the product life cycle, you should not throw this machine into the normal household garbage but ring the product to a collection point for the recycling of electrical and electronic equipment.